

| CHANNEL | | VALUE | FUNCTION |
|---------|------|--|---|
| 17ch | 37ch | | |
| 1 | 1 | 000-255 | PAN 0°→540° |
| 2 | 2 | 000-255 | PAN FINE |
| 3 | 3 | 000-255 | TILT 0°→230° |
| 4 | 4 | 000-255 | TILT FINE |
| 5 | 5 | 000-255 | ZOOM Wide→Narrow |
| 6 | 6 | 000-255 | DIMMER 0%→100% |
| 7 | 7 | 000-255 | DIMMER FINE |
| 8 | 8 | 000-007 008-015 016-131 132-139 140-181 182-189 190-231 232-239 240-247 248-255 | STROBE Close Open Strobe from Slow to Fast Open Fast Close Slow Open from Slow to Fast Open Fast Open Slow Close from Slow to Fast Open Random Strobe from Fast to Slow Open |
| 9 | | 000-255 | RED 0%→100% |
| 10 | | 000-255 | GREEN 0%→100% |
| 11 | | 000-255 | BLUE 0%→100% |
| 12 | | 000-255 | WHITE 0%→100% |
| | 9 | 000-255 | RED 1 0%→100% |
| | 10 | 000-255 | GREEN 1 0%→100% |
| | 11 | | BLUE 1 |

| | | | |
|--|----|---------|---------------------------|
| | | 000-255 | 0%→100% |
| | 12 | 000-255 | WHITE 1 0%→100% |
| | 13 | 000-255 | RED 2 0%→100% |
| | 14 | 000-255 | GREEN 2 0%→100% |
| | 15 | 000-255 | BLUE 2 0%→100% |
| | 16 | 000-255 | WHITE 2 0%→100% |
| | 17 | 000-255 | RED 3 0%→100% |
| | 18 | 000-255 | GREEN 3 0%→100% |
| | 19 | 000-255 | BLUE 3 0%→100% |
| | 20 | 000-255 | WHITE 3 0%→100% |
| | 21 | 000-255 | RED 4 0%→100% |
| | 22 | 000-255 | GREEN 4 0%→100% |
| | 23 | 000-255 | BLUE 4 0%→100% |
| | 24 | 000-255 | WHITE 4 0%→100% |
| | 25 | 000-255 | RED 5 0%→100% |
| | 26 | 000-255 | GREEN 5 0%→100% |
| | 27 | 000-255 | BLUE 5 0%→100% |
| | 28 | 000-255 | WHITE 5 0%→100% |
| | 29 | 000-255 | RED 6 0%→100% |
| | 30 | | GREEN 6 |

| | | | |
|-----------|-----------|--|---|
| | | 000-255 | 0%→100% |
| | 31 | 000-255 | BLUE 6 0%→100% |
| | 32 | 000-255 | WHITE 6 0%→100% |
| | 33 | 000-255 | RED 7 0%→100% |
| | 34 | 000-255 | GREEN 7 0%→100% |
| | 35 | 000-255 | BLUE 7 0%→100% |
| | 36 | 000-255 | WHITE 7 0%→100% |
| 13 | | 000 001-004 005-009 010-013 014-018 019-022 023-027 028-031 032-036 037-040 041-045 046-049 050-054 055-058 059-063 064-067 068-072 073-076 077-081 082-085 086-090 091-094 095-099 100-103 104-108 109-112 | CTO Null 8000K 7900K 7800K 7700K 7600K 7500K 7400K 7300K 7200K 7100K 7000K 6900K 6800K 6700K 6600K 6500K 6400K 6300K 6200K 6100K 6000K 5900K 5800K 5700K 5600K |

| | | | |
|----|---------|---------|--------------------|
| | | 113-117 | 5500K |
| | | 118-121 | 5400K |
| | | 122-126 | 5300K |
| | | 127-130 | 5200K |
| | | 131-135 | 5100K |
| | | 136-139 | 5000K |
| | | 140-144 | 4900K |
| | | 145-148 | 4800K |
| | | 149-153 | 4700K |
| | | 154-157 | 4600K |
| | | 158-162 | 4500K |
| | | 163-166 | 4400K |
| | | 167-171 | 4300K |
| | | 172-175 | 4200K |
| | | 176-180 | 4100K |
| | | 181-184 | 4000K |
| | | 185-189 | 3900K |
| | | 190-193 | 3800K |
| | | 194-198 | 3700K |
| | | 199-202 | 3600K |
| | | 203-207 | 3500K |
| | | 208-211 | 3400K |
| | | 212-216 | 3300K |
| | | 217-220 | 3200K |
| | | 221-225 | 3100K |
| | | 226-229 | 3000K |
| | | 230-234 | 2900K |
| | | 235-238 | 2800K |
| | | 239-243 | 2700K |
| | | 244-247 | 2600K |
| | | 248-255 | 2500K |
| 14 | | | COLOR MACRO |
| | | 000-007 | Null |
| | | 008-011 | Color 1 |
| | | 012-015 | Color 2 |
| | | 016-019 | Color 3 |
| | | 020-023 | Color 4 |
| | | 024-027 | Color 5 |
| | | 028-031 | Color 6 |
| | | 032-035 | Color 7 |
| | 036-039 | Color 8 | |

| | | | |
|-----------|--|---------|--|
| | | 040-043 | Color 9 |
| | | 044-047 | Color 10 |
| | | 048-051 | Color 11 |
| | | 052-055 | Color 12 |
| | | 056-059 | Color 13 |
| | | 060-063 | Color 14 |
| | | 064-067 | Color 15 |
| | | 068-071 | Color 16 |
| | | 072-075 | Color 17 |
| | | 076-079 | Color 18 |
| | | 080-083 | Color 19 |
| | | 084-087 | Color 20 |
| | | 088-091 | Color 21 |
| | | 092-095 | Color 22 |
| | | 096-099 | Color 23 |
| | | 100-103 | Color 24 |
| | | 104-107 | Color 25 |
| | | 108-111 | Color 26 |
| | | 112-115 | Color 27 |
| | | 116-119 | Color 28 |
| | | 120-123 | Color 29 |
| | | 124-127 | Color 30 |
| | | 128-131 | Color 31 |
| | | 132-135 | Color 32 |
| | | 136-165 | Clockwise Rotation, Fast to Slow |
| | | 166-195 | Counter-Clockwise Rotation, Slow to Fast |
| | | 196-205 | Red→Green Fast to Slow |
| | | 206-215 | Red→Blue Fast to Slow |
| | | 216-225 | Red→White Fast to Slow |
| | | 226-235 | Green→Blue Fast to Slow |
| | | 236-245 | Green→White Fast to Slow |
| | | 246-255 | Blue→White Fast to Slow |
| | | | PIXEL SELECT |
| | | 000-003 | Open |
| | | 004-007 | Pattern 1 |
| | | 008-011 | Pattern 2 |
| | | 012-015 | Pattern 3 |
| | | 016-019 | Pattern 4 |
| | | 020-023 | Pattern 5 |
| | | 024-027 | Pattern 6 |
| | | 028-031 | Pattern 7 |
| 15 | | | |

| | | |
|--|---------|------------|
| | 032-035 | Pattern 8 |
| | 036-039 | Pattern 9 |
| | 040-043 | Pattern 10 |
| | 044-047 | Pattern 11 |
| | 048-051 | Pattern 12 |
| | 052-055 | Pattern 13 |
| | 056-059 | Pattern 14 |
| | 060-063 | Pattern 15 |
| | 064-067 | Pattern 16 |
| | 068-071 | Pattern 17 |
| | 072-075 | Pattern 18 |
| | 076-079 | Pattern 19 |
| | 080-083 | Pattern 20 |
| | 084-087 | Pattern 21 |
| | 088-091 | Pattern 22 |
| | 092-095 | Pattern 23 |
| | 096-099 | Pattern 24 |
| | 100-103 | Pattern 25 |
| | 104-107 | Pattern 26 |
| | 108-111 | Pattern 27 |
| | 112-115 | Pattern 28 |
| | 116-119 | Pattern 29 |
| | 120-123 | Pattern 30 |
| | 124-127 | Pattern 31 |
| | 128-131 | Pattern 32 |
| | 132-135 | Pattern 33 |
| | 136-139 | Pattern 34 |
| | 140-143 | Pattern 35 |
| | 144-147 | Pattern 36 |
| | 148-151 | Pattern 37 |
| | 152-155 | Pattern 38 |
| | 156-159 | Pattern 39 |
| | 160-163 | Pattern 40 |
| | 164-167 | Pattern 41 |
| | 168-171 | Pattern 42 |
| | 172-175 | Pattern 43 |
| | 176-179 | Pattern 44 |
| | 180-183 | Pattern 45 |
| | 184-187 | Pattern 46 |
| | 188-191 | Pattern 47 |
| | 192-195 | Pattern 48 |

| | | | |
|----|----|---|--|
| | | 196-199 200-203 204-207 208-211 212-215 216-219 220-223 224-227 228-231 232-235 236-239 240-243 244-247 248-251 252-255 | Pattern 49 Pattern 50 Pattern 51 Pattern 52 Pattern 53 Pattern 54 Pattern 55 Pattern 56 Pattern 57 Pattern 58 Pattern 59 Pattern 60 Random (Pattern 1-7) Pattern 61 Open |
| 16 | | 000-031 032-091 092-101 102-161 162-255 | PIXEL ROTATION Null Clockwise Rotation, Fast to Slow Null Counter-Clockwise Rotation, Slow to Fast Null |
| 17 | 37 | 000-029 030-039 040-049 050-059 060-069 070-079 080-089 090-099 100-119 120-129 130-139 140-149 150-159 160-169 170-179 180-189 190-199 200-209 210-255 | FUNCTION Null Dimmer Curve: Linear Dimmer Curve: Square Law Dimmer Curve: Inverse Square Law Dimmer Curve: S Curve Null Dimmer Speed: Smooth Dimmer Speed: Fast Null Zoom Invert Enable Zoom Invert Disable Pan/Tilt Reset Effect Reset Color Calibration: On Color Calibration: Off Calibration Mode: High CRI Calibration Mode: High Output Reset All Null |

LED PIXEL SELECT FOR 17-CH:

| | | | | | | | |
|----------------|----------------|----------------|----------------|----------------|----------------|----------------|----------------|
| | | | | | | | |
| Value: 0-3 | Value: 4-7 | Value: 8-11 | Value: 12-15 | Value: 16-19 | Value: 20-23 | Value: 24-27 | Value: 28-31 |
| | | | | | | | |
| Value: 32-35 | Value: 36-39 | Value: 40-43 | Value: 44-47 | Value: 48-51 | Value: 52-55 | Value: 56-59 | Value: 60-63 |
| | | | | | | | |
| Value: 64-67 | Value: 68-71 | Value: 72-75 | Value: 76-79 | Value: 80-83 | Value: 84-87 | Value: 88-91 | Value: 92-95 |
| | | | | | | | |
| Value: 96-99 | Value: 100-103 | Value: 104-107 | Value: 108-111 | Value: 112-115 | Value: 116-119 | Value: 120-123 | Value: 124-127 |
| | | | | | | | |
| Value: 128-131 | Value: 132-135 | Value: 136-139 | Value: 140-143 | Value: 144-147 | Value: 148-151 | Value: 152-155 | Value: 156-159 |
| | | | | | | | |
| Value: 160-163 | Value: 164-167 | Value: 168-171 | Value: 172-175 | Value: 176-179 | Value: 180-183 | Value: 184-187 | Value: 188-191 |
| | | | | | | | |
| Value: 192-195 | Value: 196-199 | Value: 200-203 | Value: 204-207 | Value: 208-211 | Value: 212-215 | Value: 216-219 | Value: 220-223 |
| | | | | | | | |
| Value: 224-227 | Value: 228-231 | Value: 232-235 | Value: 236-239 | Value: 240-243 | Value: 244-247 | Value: 248-251 | Value: 252-255 |